

**From:** [REDACTED]  
**To:** [REDACTED]  
**Subject:** FW: Question for Bill Frederick from [REDACTED] re NFSS RI Addendum  
**Date:** Wednesday, May 19, 2010 9:23:57 AM  
**Attachments:** [REDACTED]

---

-----Original Message-----

**From:** [REDACTED]  
**Sent:** Thursday, April 08, 2010 10:30 AM  
**To:** [REDACTED]  
**Subject:** RE: Question for [REDACTED] from [REDACTED] re NFSS RI Addendum

Hello [REDACTED],

Attached is a figure provided by our contractor for the Remedial Investigation Addendum sampling. It reflects the final groundwater-monitoring well installations (the red and white circles) and the temporary well points (TWPs) that were abandoned after use (the blue circles).

Some of the new wells may become part of the annual environmental monitoring program; some abandoned TWPs did show contamination but were not kept in lieu of more optimal down-gradient monitoring points. The construction information for these wells will be available in the RI Addendum Report when it is released.

Sincerely,

[REDACTED]  
[REDACTED]  
US Army Corps of Engineers, Buffalo District  
1776 Niagara Street  
Buffalo, NY 14207

Phone: [REDACTED]

Fax: [REDACTED]

-----Original Message-----

**From:** [REDACTED]  
**Sent:** Wednesday, March 31, 2010 5:27 PM  
**To:** [REDACTED]  
**Subject:** Question for [REDACTED] from [REDACTED] re NFSS RI Addendum

Hi [REDACTED]

Unfortunately, I was unable to attend the most recent USACE public meeting, so missed the opportunity to ask questions. I do have a question for [REDACTED], who I believe was present at the meeting to answer questions about groundwater. I have been taking a look at the NFSS RI Addendum sampling plan, but am missing a piece of information. I would like to know which of the 23 TWPs are now permanent groundwater monitoring wells. The sampling plan calls for 10 of the 23 TWPs to become monitoring wells, but does not identify which wells.

Many thanks,

[REDACTED]